

Printing with the SV208 Printer

Switching ScriptView Labels (Only available in ScriptAbility v.12.10.0)

There are two styles of ScriptView Labels:



ScriptView Booklet (Standard)

Multipage Extended Content Label



ScriptView Flip (New)

Single Page Extended Content Label


You can switch between each different style when you want by doing the following:

1. Power down the printer.
2. Remove the **previous** media.
3. Insert the **new** media into the printer.

*** Be sure to align the **I-Mark** with the outer edge of the printer output.

Inside ScriptAbility Software

Be sure to choose the proper label style in ScriptAbility from the drop-down menu and initialize a print job.



NOTE

The first print may not be perfectly aligned. This is expected. After the first label, all subsequent prints should be properly aligned.

If you need to switch back to the previous media, follow these same instructions.